



## BT-100

Transport incubator

---

### Function features

Air mode and baby mode controlled by micro-computer

Use AC Power and DC Power alternatively, DC 12V or DC 24V Power on the ambulance

Set temperature, air temperature, skin temperature and internal battery power are displayed by LED Self-testing function, various failure alarms by audible and visual

Alarm function:

Power failure, Over temperature, Temperature deviation, Fan failure, Temperature sensor failure Double wall hood with side door and front door, 4 operating windows and 2 iris ports, 5 infusion seals The infant bed can be pulled out from side door easily

Natural air flow humidity

The height of whole unit is adjustable Oxygen supply system

LED observe light, adjustable brightness

Buil-in storage cabinet

---

### Optional functions



Infant Resuscitator



Low pressure aspirator



Ambulance trolley